


Scheme No B025 : Last Updated Jul 20189  
 © Free-Way 2019


# FREE-WAY SWITCH

www.freewayswitch.com


MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD




REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.



FRONT VIEW OF PICKUPS AND SWITCH



FRONT VIEW OF PICKUPS AND SWITCH



Model No:- 5B5-01




HHH Parallel Series Scheme A 1V/1T



# FREE-WAY SWITCH

www.freewayswitch.com


MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD




REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.



FRONT VIEW OF PICKUPS AND SWITCH



FRONT VIEW OF PICKUPS AND SWITCH



Refer to Free-Way Blade Installation Instructions

Note: ensure all pickups are of compatible phase/polarity


Note: Push/Pull splits humbucker to inner coil when pulled out.

Switch metalwork is assumed to be grounded by shielding on reverse of scratch-plate which is assumed grounded via the potentiometers



# FREE-WAY SWITCH

www.freewayswitch.com


MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD




REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.



FRONT VIEW OF PICKUPS AND SWITCH



FRONT VIEW OF PICKUPS AND SWITCH



Refer to Free-Way Blade Installation Instructions

Note: ensure all pickups are of compatible phase/polarity

Note: Push/Pull splits humbucker to inner coil when pulled out.


Switch metalwork is assumed to be grounded by shielding on reverse of scratch-plate which is assumed grounded via the potentiometers

Scheme No B072 : Last Updated July 2020  
 © Free-Way 2020




MANUFACTURED IN ENGLAND BY NSF CONTROLS LTD


REVERSE VIEW OF PICKUPS, SWITCH AND POTENTIOMETERS.




HUMBUCKER COLOUR KEY	
Inr/Coil Start wire	— (Red)
Inr/Coil Finish wire	— (Grey)
Otr/Coil Finish wire	- - - - (Black)
Otr/Coil Start wire	— (Black)
Shield wire	- - - - (Dotted)



FRONT VIEW OF PICKUPS AND SWITCH  
 (Assumes middle position of 3-Way Switch)



FRONT VIEW OF PICKUPS AND SWITCH



Note: terminal A is not used.

Refer to Free-Way Blade Installation Instructions  
 Switch metalwork is assumed to be grounded by shielding on reverse of scratch-plate which is assumed grounded via the potentiometers

Model No:- 5B5-01



HSH Coil-Split 1V/1T